


EPOS Manager | Firmware Update Process

EPOS Manager Cloud Solution:

- 1) The system administrator from EPOS pushes the latest firmware to the cloud.
- 2) The IT Admin logs in to the EPOS Manager cloud solution.
 - Approve the firmware/software
 - Click Deploy function
 - Select the target group, schedule time and deployment type (mandatory, optional or silent)
- 3) The end-user receives the firmware from EPOS Manager.



EPOS Manager On-Premises Solution:

- 1) The system administrator from EPOS pushes the latest firmware to the cloud.
- 2) The IT Admin logs in to the EPOS Manager cloud solution.
 - Download the firmware/software
 - Save the firmware into the on-premises solution.
- 3) The IT Admin logs in to the EPOS Manager on-premises solution.
 - Approve the firmware/software
 - Click Deploy function
 - Select the target group, schedule time and deployment type (mandatory, optional or silent)
- 4) The end-user receives the firmware from EPOS Manager.

